
# 迷你型攜帶式 H. 264 儲存器 Model:GL-D18

台灣製造 CE FCC RoHS 外銷精品

最迷你型隨身 DVR·震動提示功能·支援多種專用專業偽裝型攝影機·支援線控器 [部件說明]



- ①震動提示指撥開關
- ②錄影/覆蓋指示燈
- ③攝影機輸入埠
- ④充電/電源指示燈
- ⑤專用 USB 埠
- 6電源鍵
- ⑦錄影/停止鍵
- ⑧TF卡插槽
- ⑨自動覆蓋(循環錄影)指撥開關
- ⑩ReSet 復歸鍵

#### [操作]

準備:插入TF卡及接上專用攝影機, Vib 震動提示及 Over Write 自動覆蓋先撥好位置。

開機:長按電源鍵三秒,電源指示燈藍燈到工作指示燈綠燈亮起,表示待機中。

錄影:待機中按一次錄影鍵(Rec/Stop),燈號由綠燈轉變為紅燈時,進入錄影。

再按一次則存檔,紅燈熄滅變綠燈,回到待機模式。

關機:待機狀態下,長按電源鍵三秒,綠燈先熄,待 3~5 秒藍燈熄關機,此時才能退出 記憶卡。

線控器:關機側面插上線控器,向另一方推三秒,開機到自動錄影。存檔關機亦同。 [充電]


充電時指示燈亮綠燈, 充飽後綠燈熄, 最長充電時間勿超過 5 小時(以 5V1A) 鋰電池完全沒電後或器材存放前, 請先充飽電再存放

### [日期設定]

- 一、在根目錄下新增一個 settime.txt 文件檔,內容例如(2017年7月27日8:57:08) 2017.07.27 08:57:08
- 二、開機錄影,即可寫入設定時間。
- 三、或在記憶卡根目錄下的 SetTime 資料夾中有個 SetTime.bat 的批次檔,直接執行它,它會自動抓取您目前電腦的時間,好了之後,一樣將卡片插回 DVR 中,開機錄影一段。

## Matchbox Size DVR Model: GL-D18

### [Description]



- (1) Vibration Switch
- (2) Rec/Overwrite LED
- ③Camera In
- 4 Charge/Power LED
- ⑤Control/USB Port
- (6) Power ON/OFF
- 7) REC/STOP
- **®TF Card Slot**
- (9) Overwrite Switch
- (10) Reset Button


[Battery Charge]



With the DVR powered off, connect USB cable to ③ and the other end of the cable to a computer or a USB charger.

When fully charged, the green light will turn off. The device supports 120-150 minutes continuous recording. Every video file is approximately 30 minutes in length.

[Connecting to a Camera]



[Date & Time setting (for Windows system)]

- (1) from the desk top right-click to open Notepad, create a text(.txt) file names settime
- (2)On the first line of the file, enter date and time information as year.month.day hours.minutes.seconds.

For example, suppose the times is 2017/2/1; PM08:00, please enter 2017.02.01 20:00:00

(3)Save the file to the root directory of the memory card.

#### [Operation]

\*\*Please format the memory card on PC before recording.

- (1)Sliding the vibration switch ① to turn on/off vibration mode.
- (2) Sliding the overwrite switch (9) to turn on/off overwrite.
- (3)To power on the DVR gentely press 6 once. **Blue LED** 4 turns on. In vibration mode, DVR vibrates once when it is on.
- (4)To record, press  $\bigcirc$  once. Red LED  $\bigcirc$  turns on.

(Camera must be connected at this moment)

In vibration mode, DVR vibrates 3 times when recording starts.

- (5)To stop record, press ⑦ again. LED ② turns off.
- (6)Press 6 to turn off DVR. LED 4 turns off. In vibration mode, DVR will vibrate 5 times.

Note: The DVR will turn off automatically in 5 seconds if memory card is not placed.

Yellow LED will turn on when overwrite function is enabled.

#### Made in TAIWAN

[Exhibition center] GREENLEAF Enterprise Co., Ltd.

[Address] No. 388, Chung-Hsiao E. Rd., Sec6, Taipei City, Taiwan, R.O.C.

[E-Mail] service @taiwan-spy.com

#### [產地]臺灣

[展示中心]綠廣興業有限公司

[地址]台北市南港區忠孝東路六段 388 號

[E-Mail] service @taiwan-spy.com